



OPERATING INSTRUCTIONS FOR E7 CONTROL


E7 Control Right Side




Left Side





- 1-Seat Height Adjustment
- 2-Tension Control
- 3-Back Height Adjustment
- 4-Seat and Back Tilt Adjustment
- 5-Seat Slider



E7 Control Right Side



Left Side




Paddle (1): Seat Height Adjustment


To raise the seat height: Stand up (or raise your body; so there's no pressure on the seat), lift the paddle to raise the seat height.

To lower the seat height: Sit in the chair and lift the paddle to lower the seat height.

E7 Control Right Side



Left Side




Knob (2): Tension Control


To tighten the tension: when seated, pull out and turn the knob towards the front of the seat (clockwise).

To loosen the tension: when seated, pull out and turn the knob towards the back of the seat (counterclockwise).

E7 Control Right Side



Left Side



Back Rest (3): Back Height Adjustment


To raise the back height: place your hands on the bottom of the back rest and gently push upward.

To lower the back height: Gently push the back rest upward until it reaches its max. The back rest will then fall to the lowest height level.



Note:
Back height adjustment not available on Fino or HB chairs.

OPERATING INSTRUCTIONS FOR E7 CONTROL

E7 Control Right Side




Left Side





Knob (4): Synchronized Seat and Back Tilt Adjustment

To adjust :Turn the knob toward the front of the seat (counterclockwise) to unlock, lean back to adjust the seat and back posture. Turn the knob towards the back of the seat (clockwise) to lock in position. It can be locked in 5 positions. It has the safety feature when you turn the knob to unlock, the back won't release right away, preventing it from hitting your back. In order to change the locking position you must lean on the back, to give some pressure, to disengage the lock.

E7-SS4 Control Only Right Side



Left Side



E7-SS4 Control Only Paddle (5): Seat Slider

To adjust, sit on the chair, pull the paddle up and slide the seat forward or back to adjust seat depth.