



# OPERATING INSTRUCTIONS FOR K SERIES CONTROL (K1 & K3)

## K Series Control

### Right Side



### Left Side




- 1-Seat Height Adjustment
- 2-Tension Control
- 3-Seat and Back Tilt Adjustment





## K Series Control

### Right Side




### Left Side




**Paddle (1):  
Seat Height Adjustment**  
To raise the seat height: Stand up (or raise your body; so there's no pressure on the seat), lift the paddle to raise the seat height.  
To lower the seat height: Sit in the chair and lift the paddle to lower the seat height.

## K Series Control

### Right Side




### Left Side




**Knob (2):  
Tension Control**  
To tighten the tension: when seated, turn the knob counterclockwise.  
To loosen the tension: when seated, turn the knob clockwise.

## K Series Control

### Right Side



### Left Side



**Pull Rod (3):  
Seat and Back Tilt Adjustment**  
To tilt: Pull the rod out to unlock (the rod stays out while it's in unlocked position). Push the rod in to lock in the upright position.